

### Useful Tips

- Never use with your device directly over your head.
- Always swing the Platform so it is not directly over you before you go to sleep.
- You can clean your entire LEVO™ with a cloth and mild detergent.

MTM, Inc. is not responsible for damage to any device caused by improperly securing device to LEVO.

### MTM Warranty



Reading is for a lifetime, and we're dedicated to making your reading experience the best it can be. When you purchase a LEVO Holder, you're making an investment in your future. That's why we provide a Limited Lifetime Warranty with this model# 33501.

SEE OUR WEBSITE FOR FULL DETAILS: [www.BookHolder.com](http://www.BookHolder.com).

# Questions?

## Please do not contact your retailer

As the manufacturer, we are most knowledgeable of this item. If you have any questions or issues regarding your new LEVO, use one of the methods below to contact our customer service.

Phone: 1-800-928-2322

Outside the USA 1-863-815-7077

email: [sales@bookholder.com](mailto:sales@bookholder.com)


[www.bookholder.com](http://www.bookholder.com)

**MTM Inc., U.S.A.**

U.S. Patent No. 7,040,591 other patents pending  
made in china


# Levo

Experience The Ultimate Power of  
Reading and Surfing




## iCLAMPON STAND FOR iPADS, EBOOKS, AND TABLETS

ASSEMBLY • MODEL #33504



### GETTING STARTED

Congratulations! You're about to assemble a revolutionary product that will help you surf & read more comfortably, longer, and smarter. Unpack your LEVO and compare its contents to the parts shown here.




### 1 ADJUSTING THE ROLL TENSION

**Note: This step may have been done in our factory.** To test, the elbow should rotate around the arm but should not pull off the arm. If the elbow pulls off: a. Tap the elbow to assure it is all the way on the arm. b. Use a small Phillips head screwdriver to lightly tighten the screw that is already housed inside the bottom of the elbow.

## 2 SECURING THE V PLATE

Align the parts as shown, then hand tighten the V Plate Knob. The rubber pad protects the underside of your furniture. You can omit this part if desired.




## 3 SECURING YOUR DEVICE

Each Cord fits diagonally across a corner of your device (see images below).

**The Cords do not need to be super tight on your device.** As long as they stretch to the contour of your device, they are tight enough. Start by holding the platform on your lap. You might want to center your device, or position it towards the bottom to allow space for a clip-on light such as our LEVO Light. Install the Cords in the order specified in the diagram. **While installing Cord 2, push your device into Cord 1 so it stretches and slightly tightens your device to the platform.** Be sure Cord 3 & 4 are stretched over your device as well. With all 4 Cords installed test your installation by holding the platform slightly above a soft surface (such as a couch or chair) and jiggling it a few times. Your device should not release from the Cords.

INSTALL THIS CORD **1**ST.




INSTALL THIS CORD **3**RD.

INSTALL THIS CORD **2**ND.

## Releasing Your Device


It's now quick and easy to secure and release your device! To release your device, simply stretch each Cord off your device. To secure again, simply stretch each Cord over a corner of your device.



CORD PATH WHEN USED WITH THICK CASE OR THICK DEVICES.



CORD PATH WHEN USED WITH THIN DEVICES. NOTE THAT THE CORD FORMS A SECOND LOOP TO TAKE UP SLACK.



BACK VIEW OF PLATFORM AND CORD CLIPS

## 4 YOUR LEVO eBook/TABLET HOLDER IS NOW READY TO SHOW YOU THE COOLEST WAY TO READ AND SURF!


Your LEVO V Clamp-on Stand is specially designed to clamp onto the corner of side-tables with a minimum overhang of just 1/4 of an inch (6.4mm) on the front and side. It can also clamp to table sides where the minimum overhang is 1 3/4 inches (4.5 cm).

**CAUTION:** Do not use this device on glass top tables or the table may break. Be sure the table or cart you clamp this device to is strong enough to handle the loading forces. Wooden table tops should have a minimum thickness of 5/8 of an inch.

Always remove the Platform before clamping or unclamping your LEVO.



## CORNER MOUNTING



## SIDE MOUNTING

